

Troubleshooting- Light Not Turning On

Wave the magnet over the solar panel at night until you find the activation area which changes the brightness level.

Make a quick up & down motion over this area to change between brightness levels and OFF.

***NOTE:** moving too slowly may activate the magnet switch multiple times going through multiple levels at once. A quick motion will help!*

CHANGING LED COLORS

Hold the magnet over the activation area for 5 seconds until the LED color changes.

Note: After a few days of low/no sun light or if the light is on high power setting #7, the light may turn to **OFF** mode.

Reactivate the light by waving the magnet over the activation area again.

We recommend only using high power setting #7 for short periods of time. Ideal power setting is between 2-5. Setting #1 is recommended for winter use

NEW MAGNET SWITCH OPERATION

